

SK-105
STARTER REPAIR KIT
PARTS LIST

<i>Qty.</i>	<i>Description</i>
1	Drive end housing bushing
1	Armature shaft thrust washer
1	Shift lever nut and lock washer
4	Brush springs
4	Brush holders
4	Brushes
4	Brush screws and lock washers
1	Positive brush lead.
2	Brush lead to field coil attaching screws and lock washers
1	Com-end bushing
1	Spacer washer, leather
2	Thru bolt lock washers